



***Danger- To reduce the risk of fire or electric shock, carefully follow these instructions.***

- Always turn off power at mains switch prior to installation.
- Electric current at 2 Ampere
- Optional branch circuit modules
- High temperature resistant: at least 90°C (194°F)
- Transformers must be installed away from heat sources.

- Valve-regulated, sealed, lead-acid battery

**Caution: Do not charge in a gas tight container.**